MCS-4™ Instruction Set

[Those instructions preceded by an asterisk (*) are 2 word instructions that occupy 2 successive locations in ROM]

MACHINE INSTRUCTIONS

MNEMONIC	OPR $D_3 D_2 D_1 D_0$	OPA $D_3 D_2 D_1 D_0$	DESCRIPTION OF OPERATION
NOP	0 0 0 0	0 0 0 0	No operation.
*JCN	0 0 0 1 $A_2 A_2 A_2 A_2$	$C_1 C_2 C_3 C_4$ $A_1 A_1 A_1 A_1$	Jump to ROM address $A_2 A_2 A_2 A_2$, $A_1 A_1 A_1 A_1$ (within the same ROM that contains this JCN instruction) if condition $C_1 C_2 C_3 C_4$[1] is true, otherwise skip (go to the next instruction in sequence).
*FIM	0 0 1 0 $D_2 D_2 D_2 D_2$	R R R 0 $D_1 D_1 D_1 D_1$	Fetch immediate (direct) from ROM Data D_2, D_1 to index register pair location RRR.[2]
SRC	0 0 1 0	R R R 1	Send register control. Send the address (contents of index register pair RRR) to ROM and RAM at X_2 and X_3 time in the Instruction Cycle.
FIN	0 0 1 1	R R R 0	Fetch indirect from ROM. Send contents of index register pair location 0 out as an address. Data fetched is placed into register pair location RRR at A_1 and A_2 time in the Instruction Cycle.
JIN	0 0 1 1	R R R 1	Jump indirect. Send contents of register pair RRR out as an address at A_1 and A_2 time in the Instruction Cycle.
*JUN	0 1 0 0 $A_2 A_2 A_2 A_2$	$A_3 A_3 A_3 A_3$ $A_1 A_1 A_1 A_1$	Jump unconditional to ROM address A_3, A_2, A_1.
*JMS	0 1 0 1 $A_2 A_2 A_2 A_2$	$A_3 A_3 A_3 A_3$ $A_1 A_1 A_1 A_1$	Jump to subroutine ROM address A_3, A_2, A_1, save old address. (Up 1 level in stack.)
INC	0 1 1 0	R R R R	Increment contents of register RRRR.[3]
*ISZ	0 1 1 1 $A_2 A_2 A_2 A_2$	R R R R $A_1 A_1 A_1 A_1$	Increment contents of register RRRR. Go to ROM address A_2, A_1 (within the same ROM that contains this ISZ instruction) if result ≠ 0, otherwise skip (go to the next instruction in sequence).
ADD	1 0 0 0	R R R R	Add contents of register RRRR to accumulator with carry.
SUB	1 0 0 1	R R R R	Subtract contents of register RRRR to accumulator with borrow.
LD	1 0 1 0	R R R R	Load contents of register RRRR to accumulator.
XCH	1 0 1 1	R R R R	Exchange contents of index register RRRR and accumulator.
BBL	1 1 0 0	D D D D	Branch back (down 1 level in stack) and load data DDDD to accumulator.
LDM	1 1 0 1	D D D D	Load data DDDD to accumulator.

INPUT/OUTPUT AND RAM INSTRUCTIONS

(The RAM's and ROM's operated on in the I/O and RAM instructions have been previously selected by the last SRC instruction executed.)

MNEMONIC	OPR $D_3 D_2 D_1 D_0$	OPA $D_3 D_2 D_1 D_0$	DESCRIPTION OF OPERATION
WRM	1 1 1 0	0 0 0 0	Write the contents of the accumulator into the previously selected RAM main memory character.
WMP	1 1 1 0	0 0 0 1	Write the contents of the accumulator into the previously selected RAM output port. (Output Lines)
WRR	1 1 1 0	0 0 1 0	Write the contents of the accumulator into the previously selected ROM output port. (I/O Lines)
WRϕ[4]	1 1 1 0	0 1 0 0	Write the contents of the accumulator into the previously selected RAM status character 0.
WR1[4]	1 1 1 0	0 1 0 1	Write the contents of the accumulator into the previously selected RAM status character 1.
WR2[4]	1 1 1 0	0 1 1 0	Write the contents of the accumulator into the previously selected RAM status character 2.
WR3[4]	1 1 1 0	0 1 1 1	Write the contents of the accumulator into the previously selected RAM status character 3.
SBM	1 1 1 0	1 0 0 0	Subtract the previously selected RAM main memory character from accumulator with borrow.
RDM	1 1 1 0	1 0 0 1	Read the previously selected RAM main memory character into the accumulator.
RDR	1 1 1 0	1 0 1 0	Read the contents of the previously selected ROM input port into the accumulator. (I/O Lines)
ADM	1 1 1 0	1 0 1 1	Add the previously selected RAM main memory character to accumulator with carry.
RDϕ[4]	1 1 1 0	1 1 0 0	Read the previously selected RAM status character 0 into accumulator.
RD1[4]	1 1 1 0	1 1 0 1	Read the previously selected RAM status character 1 into accumulator.
RD2[4]	1 1 1 0	1 1 1 0	Read the previously selected RAM status character 2 into accumulator.
RD3[4]	1 1 1 0	1 1 1 1	Read the previously selected RAM status character 3 into accumulator.

ACCUMULATOR GROUP INSTRUCTIONS

CLB	1 1 1 1	0 0 0 0	Clear both. (Accumulator and carry)
CLC	1 1 1 1	0 0 0 1	Clear carry.
IAC	1 1 1 1	0 0 1 0	Increment accumulator.
CMC	1 1 1 1	0 0 1 1	Complement carry.
CMA	1 1 1 1	0 1 0 0	Complement accumulator.
RAL	1 1 1 1	0 1 0 1	Rotate left. (Accumulator and carry)
RAR	1 1 1 1	0 1 1 0	Rotate right. (Accumulator and carry)
TCC	1 1 1 1	0 1 1 1	Transmit carry to accumulator and clear carry.
DAC	1 1 1 1	1 0 0 0	Decrement accumulator.
TCS	1 1 1 1	1 0 0 1	Transfer carry subtract and clear carry.
STC	1 1 1 1	1 0 1 0	Set carry.
DAA	1 1 1 1	1 0 1 1	Decimal adjust accumulator.
KBP	1 1 1 1	1 1 0 0	Keyboard process. Converts the contents of the accumulator from a one out of four code to a binary code.
DCL	1 1 1 1	1 1 0 1	Designate command line.